


RUSSIAN:


1.Разбираем асик и вытаскиваем контрольную плату чтобы появился доступ к SD гнезду, можно отключить питание (6пин) от все хэш плат и интернет и оставить питание контрольной платы при желании

2. Выключаем питание и переставляем джампера на контрольной плате

Изначально на контролке джампера стоят вот так:




Ставим их вот в такое положение:




3. Включаем контрольку с воткнутой SD картой и ждем 60 секунд до начала моргания светодиодов.
4. Выключаем асик , вытаскиваем флешку , переставляем джампера обратно и собираем асик
5. На асике будет установлена прошивка VNISH

ENGLISH:

1. We disassemble the ASIC and pull out the control board so that access to the SD slot appears, you can turn off the power (6pin) from all the hash boards and the Internet and leave the power to the control board if desired
2. Turn off the power and rearrange the jumpers on the control board Initially, the jumper controls are like this:



We put them in this position:



3. Turn on the control board with an inserted SD card and wait 60 seconds before the LEDs blink.
4. Turn off the ASIC, pull out the USB flash drive, rearrange the jumpers
5. VNISH firmware is installed